AIR RUNNER
SELF BALANCING SCOOTER
USER MANUAL

LEGAL DISCLAIMER

This page contains important legal notices regarding disclaimers, copyrights, purchaser's responsibility, inherent risks, and release of liability. Please read and understand the following information thoroughly before purchasing any product from us. Also read our Warranty information. Please direct any questions to support@airrunner.co.uk.

DISCLAIMERS

The products sold by Air Runner Ltd are designed for recreational and/or for personal transportation of a single rider with proper safety equipment. Our scooters are classed as toys and are not suitable for handicapped persons or persons with limited mental or physical capacities. The product is to be used only on safe, dry, smooth indoor flooring or hard packed indoor surfaces, in accordance with UK regulations, during daylight hours. Self balancing scooters are not designed to operate outside and should never be used on pavements, roads or similar.

There are inherent dangers to using motorised scooters. Purchaser shall use product at their own risk and seller will not be held liable under any circumstance for incidental or consequential loss or damage or injury, due directly or indirectly to the use of this product, including any malfunction.

Children above 10 years of age may use products under adult supervision and under the guardian's own discretion. Adult guardian assumes all responsibilities associated with the use of these products by minors. Customers understand that the use of these products can cause injury or death. To prevent it, we strongly recommend the use of safety equipment such as helmet and knee and elbow pads. The user holds Seller and his agents harmless from any liability. Purchaser obtains her/his own insurance. Seller assumes no suitability of any of these products as to size; age and other factors largely depend on personal discretion.

Warranties will be void if the product is ever used in any competitive sport, altered, misused or modified, ridden by more than one person at a time, or used on any other surface than specified in our usage information or for stunt riding, jumping or similar activity.

RELEASE

The User releases Air Runner Ltd, it's officers, agents, sponsors and employees from claims, demands and damages (both actual and consequential), of every kind and nature, known and unknown, suspected and unexpected, disclosed and undisclosed, arising out of or in any way connected with items purchased from us, or purchases made through our website or our official retail partners websites or affiliates.

LIMITATION OF LIABILITY

In no event shall Air Runner Ltd or its suppliers be liable for lost profits or any special, incidental or consequential damages arising out of or in connection with our company or items purchased on or through our site or this agreement (however arising, including negligence). Our liability, and the liability of our suppliers, to you or any third parties in any circumstance is limited to the User's cost of qualifying products purchased at the time of entering into the agreement. Qualifying products as acceptable for return as outlined in the return policy.

WARRANTY

This Limited Warranty applies to physical goods, and only for physical goods, purchased from Air Runner Ltd (the “Physical Goods”)

What does this limited warranty cover?

This Limited Warranty covers any manufacturing defects in materials under normal use during the Warranty Period. The Limited Warranty only covers the component product parts; integral motor, battery, PCB and gyroscopic sensor. All general “wear and tear” or scratching, cracks or damages to the external or internal parts of the scooter are not covered in this warranty.

This warranty does not include claims for limitation of the implied warranties of merchantability, fitness for a particular purpose, or non-infringement.

During the Warranty Period, Air Runner Ltd will repair or replace, at no charge, parts of a product that proves defective because of improper material manufacturing defects, under normal use and maintenance.

This Limited Warranty extends to the original purchaser only and is not transferable.

What will we do to correct problems?

Air Runner Ltd will replace the Parts at no charge, using new or refurbished replacement parts. Providing they have been used in the proper manor outlined in this manual.

How long does the coverage last?

The Warranty Period for Physical Goods purchased from Air Runner Ltd is 2 Years from the date of purchase.

A replacement Physical Good or part assumes the remaining warranty of the original Physical Good or 2 Years from the date of replacement or repair, whichever is longer.

What does this limited warranty not cover?

This Limited Warranty does not cover any problem that is caused by:

- Conditions, malfunctions or damage not resulting from manufacturing defects in material
- Conditions, malfunctions or damage resulting from negligence, improper maintenance or modification- damaged or destroyed by natural causes including but not limited to lightning, flood, or other natural disaster- theft or loss of the Physical Goods

This Limited Warranty does not cover any shipping charges, handling charges, gift wrap fees or taxes. You are responsible for and must prepay all shipping charges.

You shall assume all risk of loss or damage to the Physical Good while in transit to Air Runner Ltd.

This Limited Warranty is void if the Physical Goods are returned with removed, damaged or tampered labels or any alterations.

What do you have to do?

To obtain warranty service, you must first contact us to determine the problem and the most appropriate solution for you.

Deliver the Physical Goods, in either its original packaging or packaging providing an equal degree of protection, including any accessories or documents that shipped with the Physical Goods to the address specified by Air Runner Ltd.

Air Runner Ltd, reserve the right to amend or charge our warranty at any time and without any notice.

After purchasing your scooter, you must register your product with us, by sending an email to: warranty@airrunner.co.uk - the email to us must contain your full name, address, contact number, email address, date purchased and outlet that you purchased from. Failure to do so will mean your warranty is void and we do not accept any responsibility for late submissions or any claim for damages if you do not register. You must register your warranty within 14 working days of purchase.

You can contact us by any of the following contact methods:

- By email: warranty@airrunner.co.uk

INDEMNIFICATION

User hereby agrees to defend, indemnify and hold harmless Air Runner Ltd, it's officers, directors, employees and agents, for any loss or damages awarded by a court of competent jurisdiction resulting from any claim, action, or demand, including reasonable solicitors fees, arising out of or related to products purchased from Air Runner Ltd or the violation of the agreement by the User.

Purchaser acknowledges having read and understood the use of these products before purchasing. This shall not act as a waiver of any implied warranties which customer retains, as provided by law.

PURCHASER RESPONSIBILITY

You must inspect all equipment before using it and to take full responsibility for assuring that the equipment is in good working order and safe to use. This includes, but is not limited to, ensuring that all bolts are tight prior to riding (bolts sometimes loosen during shipment or while riding), tires are properly inflated (if applicable).

You further understand that you are responsible for damage to equipment.

Purchaser understands the nature of scooter riding and related activities and acknowledges that Purchaser is qualified to operate said scooter, and is in proper physical condition to participate in such activity. Purchaser agrees to assume all risks when allowing others to operate Purchaser's scooter. If Purchaser is not familiar with the nature of scooter riding, Purchaser should seek professional training before operating a scooter.

INHERENT RISKS

Warning! Scooter riding activities involve the risk and danger of serious bodily injury including, but not limited to, disability, paralysis, dismemberment and death. These inherent risks and dangers may be caused by Purchaser's own actions or inactions, the actions or inactions of others, participating or not participating in the activity, the condition in which the activity takes place, or the negligence of others. There may be additional risks, including social and economic loss, either known or unknown to Purchaser, not readily foreseeable, and Purchaser fully accepts and assumes responsibility for all such risks, losses, costs, and damages incurred as a result of Purchaser s participation in scooter riding activity.

OPERATIONAL INSTRUCTIONS



OPERATIONAL INSTRUCTIONS

Turn on scooter at the power switch before standing on the board, listen for noise signalling powering on of the board. You should see a green light indicating that the board has successfully turned on.

Our board has the following “lock up” safety feature, if one or more of the below are present, your scooter will “lock up” for your own safety, when in this mode - you should hear a buzzer or beeping. For more information contact: support@airrunner.co.uk

- Climbing surface is greater than 10 degrees
- The battery voltage is too low
- In the process of charging
- Not enough battery, needs charging
- Body rocking back and fourth for more than 30 seconds
- Forwards and backwards more than 35 degrees continuously

OPERATIONAL INSTRUCTIONS

Make sure you are wearing all safety equipment, step on to black pressure sensitive pads with both feet, one after the other. If you hear a continuous “beeping” noise, the scooter may not be level.



Step 01



Step 02

OPERATIONAL INSTRUCTIONS

Make sure you are on an even surface, then try leaning forwards and backwards slowly to get a feel for the movement of the board. Bending your knees slightly and keep your feet against the edge of the board helps with balance.

Warning: your Air Runner board can be difficult at first and will pick up speed quickly, make sure you feel comfortable before attempting sharper turns and faster riding.



Step 03



Step 04

OPERATIONAL INSTRUCTIONS

Turning of the board is easy. Pressure applied on one side more than other creates a turn. One foot back and one foot forward makes the board spin.





CHARGING INSTRUCTIONS

Warning: your scooter has a lithium-iron battery inside and must be handled with care. If you think damage has been caused and you do not think it is safe to ride. You must seek proper advice, leakage of materials and battery damage can be extremely harmful.

You should speak with Air Runner Ltd at support@airruner.co.uk immediately if you notice one of the below or any other danger that you think may be harmful to you or the user;

1. Their is a strange smell or odour resonating from the scooter or battery
2. There is a leak of chemical or material out of the scooter
3. Fire or intense emittance of heat from the scooter

Removal of the battery is strictly prohibited and should only be removed and replaced by Air Runner Ltd or its affiliates, if you notice any of the above.

Do not touch the leakage of any material
Do not let a human or animal come into contact with the chemical or scooter
Do not attempt to charge the battery
Do not open the battery
Do not try to insert any material into the battery

Lithium-iron batteries are prohibited by waste authorities and you should seek further advice from your local authority on disposal of your scooter

CHARGING INSTRUCTIONS

Warning: your scooter needs mains power (electricity) to charge, there is a possibility of injury or death. The plugging in of your scooter to mains power (electricity) should be carried out by a competent person only.

1. Make sure the charging inlet is dry and free from dust or debris.
2. Insert the charger into inlet, red light on charger indicates the charging of scooter.
3. When charging of your scooter is full, the charging indicator light will change to green.

When the green light is shown, make sure you remove the charging lead. Over charging of the scooter can lead to battery failure and could damage the battery. Charging time normally takes around 2hrs, you should remove the charger after 2hrs.

SPECIFICATION

Note: your scooter has a specification and proper guidelines, you should operate within these guidelines to make sure the integral components are not damaged through improper use.

Description	Value
Chassis dimensions	584x186x178mm (Lx-WxH)
Chassis clearance	30mm
Tyre size	170mm
Body weight	12.7kG
Max cruise speed	10mph
Max mileage	15 miles (on one charge)
Battery	Samsung 16wwh (20pc Li-on battery)
Charging time	1-2hrs

Description	Value
Voltage	36v
Initial capacity	2-4AH
Working temperature	-15°c - 50°c
Charging temperature	0 - 40°c
Storage time	11 months
Storage temperature	-20°c - 25°c
Stored relative humidity	5% - 95%
IP rating	IP54 Splash proof
Minimum person weight	35kG
Maximum person weight	120kG

KEEP IN TOUCH

Please let us know what you think of our scooter and any changes or problems, contact: support@airrunner.co.uk

Tag us on Instagram and Facebook with the hashtag #airrunner

https://www.facebook.com/airrunner.co.uk

airrunner.co.uk

THANK YOU FOR YOUR PURCHASE

From all of the team at Air Runner, thank you for your purchase.

Copyright Air Runner ltd © 2015